

FutureNow FNIP-12xDIO

Installation and Operations Manual

rev 10.10.2023

12 Channel Relay Switch with Local Inputs and IP communication

/DIN Rail Mountable



Figure 1. The FNIP-12xDIO relay module

TABLE OF CONTENTS

INSTALLATION	3
Terminal connections	3
Wiring diagrams	5
Local Inputs	6
Outputs	6
CONFIGURATION	7
Configuration via the web interface	7
Network settings	8
Username and password settings	9
Channel settings	10
Scenes	11
Firmware Upgrade	12
Resetting to factory defaults	12
OPERATION	13
Operation via the local inputs	13
Input modes	13
Operation via the built-in web server	14
Control page	14
Input page	15
Operation via TCP	16
TECHNICAL SPECIFICATIONS	17



INSTALLATION

WARNING!

This equipment shall be installed in a closed cabinet with no access to live parts. Only the top enclosure of the equipment (where the label is affixed) is allowed to be accessed by the operator.

Since the module is connected to mains/line voltage, it must be installed by a qualified electrician in accordance with local electrical codes.

Turn off power (main circuit breaker) before installation.

Terminal connections

Each module has a wiring diagram on the front which can help the installer when connecting the modules at installation sites. See figure 2.




Figure 2. The FNIP-12xDIO relay module




The terminal connections of the FNIP-12xDIO are listed in Table 1.

Pos.	Description	Pos.	Description
1.	Output 1	27.	Input 1
2.	Output 1	28.	Input 1 Com
3.	Output 2	29.	Input 2
4.	Output 2	30.	Input 2 Com
5.	Output 3	31.	Input 3
6.	Output 3	32.	Input 3 Com
7.	Output 4	33.	Input 4
8.	Output 4	34.	Input 4 Com
9.	Output 5	35.	Input 5
10.	Output 5	36.	Input 5 Com
11.	Output 6	37.	Input 6
12.	Output 6	38.	Input 6 Com
14.	Output 7	39.	Input 7
15.	Output 7	40.	Input 7 Com
16.	Output 8	41.	Input 8
17.	Output 8	42.	Input 8 Com
18.	Output 9	43.	Input 9
19.	Output 9	44.	Input 9 Com
20.	Output 10	45.	Input 10
21.	Output 10	46.	Input 10 Com
22.	Output 11	47.	Input 11
23.	Output 11	48.	Input 11 Com
24.	Output 12	49.	Input 12
25.	Output 12	50.	Input 12 Com
		51.	Power for the Main Circuit -
		52.	Power for the Main Circuit + (12V – 24V DC)


Table 1: FNIP-12xDIO terminal connectors

Wiring diagrams

Input Wiring diagram



Output Wiring diagram



The output in this example is used to switch line voltage. Since the outputs provide dry contacts, any voltage that doesn't exceed the specifications can be switched.

If mains voltage is switched, outputs 1-6 must be on the same phase, so must output 7-12. The two groups can be on different phases.

Recommended wire types

- Ethernet cable: Twisted pair, CAT5 or better.
- Outputs: According to the load attached to the outputs (current and voltage ratings).
- Inputs: A pair of low voltage cable. The inputs use low voltage signals.

All wires used and the way they are run must be in accordance with the local electrical codes.

Local Inputs

For each channel, there is a local input to allow manual operation. Please note that the inputs have voltage on them. Any voltage connected to the input terminals may damage the input circuits.

Communication LEDs

Con LED - green

The Con LED is on when the module is connected to the Ethernet network.

Act LED - yellow

The Act LED indicates that communication via Ethernet is in progress.

St LED - red

The status LED indicates that the boot loader of the module is active. This should only happen during firmware update.

Please never disconnect power from the module while this LED is on!

If this LED stays on after the firmware update, contact your distributor or technical support!

Outputs

The FNIP-12xDIO has 12 relay outputs. All outputs are dry contacts.

CONFIGURATION

Configuration can be done either via the built-in website or via TCP/IP connection. In the latter case the configuration interface the third-party controller provides is used.

Configuration via the web interface

Use the FNIP Network Discovery Utility software to find all FutureNow IP devices on your network. Alternatively, you can use third-party IP scanner utilities.

Connecting to the module's web server


You can access the module's internal website from an Internet browser using the IP address.

By default, each module obtains an IP address from a DHCP server automatically.

If there's no DHCP server available on the network, 192.168.1.25 will be assigned to the module. The same IP address will be used when connecting the module directly to your computer with an Ethernet cross cable.

Authentication

Once connected to the module's website, you will be asked to identify yourself, as seen in figure 6.



The screenshot shows a login form with the following fields:

- User Name: admin
- Password: (empty field)
- Remember this password:
- Buttons: Cancel (blue) and Log (blue)

Figure 6. Authentication Window

The default user name:**admin**

The default password:**futurenow**

The default user has administrator rights and offer access to all settings and functions.



Network settings

Network Settings Scenes Users

Network settings:

Host Name: FNIP12XDIO

Enable DHCP

Enable TCP

Enable HTTP Authentication

Enable Broadcast Messages

TCP Port: 7078

IP Address: 192.168.11.10

Gateway: 192.168.11.1

Subnet Mask: 255.255.0.0

Primary DNS: 192.168.11.1

Secondary DNS: 0.0.0.0

Multicast Address: 224.5.5.1

MAC Address: 8C:1F:64:65:3F:FD

TCP connections: 0/4

You can choose between using DHCP or static IP address here.

Enable HTTP authentication

HTTP authentication can be disabled to make HTTP communication easier for third party applications.

Enable broadcast messages

FNIP modules periodically send out heartbeat broadcast messages with basic information about themselves. This helps discovery tools and mobile apps to find them. These broadcasts can be disabled if constant traffic on the network is not desirable.

Please note that disabling broadcast messages will prevent the Discovery Tool and the mobile applications from finding the modules on the network.


Multicast address

Used to create groups of FNIP modules that react to scene activation commands received from a module with the same multicast address.


More information about scenes can be found in the Scenes chapter.

Figure 7. Network Configuration Page

Username and password settings



Username and password settings



Username:

Password:

Verify password:


Three different users can be defined, each can have three different user rights: **admin**, **actor** and **observer**.

Admins have access to all functions, including control of the outputs, monitoring the status of the inputs, outputs and changing all the settings.

Actors are allowed to control the outputs and monitor the status of the inputs and the outputs but are not allowed to change any settings.

Observers are allowed to monitor the status of inputs and outputs but not allowed to control the outputs, nor can they change any settings.

User Administration



Users:

Username:

User role:

User Enabled


Password:

Verify password:

Figure 8. User Configuration Page

Channel settings

On the **Settings** page the outputs and inputs can be renamed. Input modes can also be chosen here. The input mode determines the logical connection between the input and the output of a given channel. For more details on possible input modes and how they work, see **Operation via the local inputs** section of this document.



The screenshot shows the 'Settings' page of the FNIP-12xDIO web interface. At the top, there is a navigation bar with links for Control, Input, Network, Settings (which is highlighted in orange), Scenes, Users, Firmware, and Logout. The main content area is titled 'FNIP-12xDIO' and contains a table for managing 12 channels. The columns in the table are: Output labels, Input labels, Input modes, Monostab. duration, Scene no., and Inverted input. Each row represents a channel from 1 to 12. The 'Inverted input' column contains checkboxes, with the second row checked. The 'Input modes' column includes options like Toggle, Independent, Follow, Monostab., Switch, Scene on close, and Scene on open. The 'Monostab. duration' column has a dropdown set to 10. The 'Scene no.' column has dropdowns for each channel. The 'Inverted input' column has checkboxes for each channel.

Output labels:	Input labels:	Input modes:	Monostab. duration:	Scene no.	Inverted input
Output 1	Input 1	Toggle	10	1	<input type="checkbox"/>
Output 2	Input 2	Independent	10	1	<input checked="" type="checkbox"/>
Output 3	Input 3	Follow	10	1	<input type="checkbox"/>
Output 4	Input 4	Monostab.	10	1	<input type="checkbox"/>
Output 5	Input 5	Switch	10	1	<input type="checkbox"/>
Output 6	Input 6	Scene on close	10	3	<input type="checkbox"/>
Output 7	Input 7	Scene on open	10	6	<input type="checkbox"/>
Output 8	Input 8	Toggle	10	1	<input type="checkbox"/>
Output 9	Input 9	Toggle	10	1	<input type="checkbox"/>
Output 10	Input 10	Toggle	10	1	<input type="checkbox"/>
Output 11	Input 11	Toggle	10	1	<input type="checkbox"/>
Output 12	Input 12	Toggle	10	1	<input type="checkbox"/>

Other settings:

Resume light levels after power outage:

Save Settings

Figure 9. Channel Settings Page



Scenes

Scenes are predefined states of the outputs.

FutureNow Scenes are developed to provide group commands for FutureNow modules used in stand-alone mode. Any input of any module in the group can trigger actions for any outputs in the same group of modules.

If a module receives a **Scene Activation Command (SAC)**, the designated outputs will go to a pre-defined state. SAC can be triggered by an input change on the same module or on any module in the group.

Each module in the group must have the same multicast address set on the Network page. Modules in other groups will not react to the SAC.

	Output 1	Output 2	Output 3	Output 4	Output 5	Output 6	Output 7	Output 8	Output 9	Output 10	Output 11	Output 12	Output 13
Scene 0	Off	Off	Off	Off									
Scene 1	On	On	-	-	-	-	-	-	-	-	-	-	-
Scene 2	Off	Off	-	-	-	-	-	-	-	-	-	-	-
Scene 3	-	-	-	-	-	-	-	-	-	-	-	-	-
Scene 4	-	-	-	-	-	-	-	-	-	-	-	-	-
Scene 5	-	-	-	-	-	-	-	-	-	-	-	-	-
Scene 6	-	-	-	-	-	-	-	-	-	-	-	-	-
Scene 7	-	-	-	-	-	-	-	-	-	-	-	-	-
Scene 8	Off	Off	Off	Off									
Scene 9	On	On	On	On									

Global scenes: Enabled Enables scenes between other FNIP modules on the same subnetwork
Multicast address: 224.5.5.1

Figure 10. Scene setting page

Firmware Upgrade




Figure 11. Firmware upgrade page

Upgrading the firmware in the module is possible via the network.

On the **Firmware** page click browse and find the new firmware on your PC. The latest firmware versions are always downloadable from P5's website. Then click **Upload**. The **St** LED turns on and stays on or blinks during firmware update. After uploading the new firmware – which takes about a minute – the module will automatically restart.

The current firmware version and the time since the last reset are also displayed on this page.

Resetting to factory defaults

Holding the reset button for at least 2 sec while powering up the module will set all the settings to factory defaults. **Make sure you release the button when the red LED comes on.**

OPERATION

Operation via the local inputs

The inputs can be activated by shorting (or opening) the appropriate input terminal.

Input modes

The inputs are factory defaulted to toggle mode and can be changed via the web interface of the module as seen in **Figure 9. Channel Settings Page** or by TCP/IP commands. The input modes work as follows

1. Toggle mode (factory default)

Each short button press toggles the corresponding output

2. Independent inputs

Inputs has no effect on the channel. However, the measured resistance will still be reported via the open TCP/IP sockets and on the **Input** page of the built-in website. This can be used for monitoring the status of connected to the inputs or to activate lighting scenes or macros whenever the input gets triggered.

3. Input follow mode

The status the outputs will follow the state of the corresponding input. The output will be on while the momentary switch is pressed and off while it is released.

4. Monostable mode

The outputs can be programmed to turn on for an adjustable amount of time when the corresponding input trigger got off. (Timer start, when the input contact is released e.g: staircase lighting).

5. Switch mode

This mode makes it possible to use maintained (standard light switches) instead of momentary switches on the inputs. Each trigger of the switch (On or Off) will toggle the outputs. Please note that the position of the switch – similarly to three-way switches – will not determine the status of the output.

6. Scene on open mode

If an input gets inactive the scene assigned to the input will be executed.

7. Scene on close mode

If an input gets active the scene assigned to the input will be executed.



8. Inverted Input

This checkbox inverts the active mode of the inputs. Opening (open circuit) the input instead of closing (short circuit) will be considered active.

Operation via the built-in web server

Control page

Once logged in, you will automatically be directed to the control page, where you can control the outputs directly.




Figure 12. Control Page



Input page

This page displays the logical status of the inputs.

Input	Status
Input 1	Closed (Green)
Input 2	Open (Grey)
Input 3	Open (Grey)
Input 4	Open (Grey)
Input 5	Closed (Green)
Input 6	Open (Grey)
Input 7	Open (Grey)
Input 8	Open (Grey)
Input 9	Closed (Green)
Input 10	Open (Grey)
Input 11	Open (Grey)
Input 12	Open (Grey)

Figure 13. Input Page

Operation via TCP

To achieve the easiest integration with most controllers used in home and commercial applications, the module can be controlled by raw TCP protocol using simple ASCII based commands.

The TCP/IP communication can be enabled/disabled via the Network settings screen.

The TCP Communication Protocol Description is available upon request.

Event notifications

Automatic event notifications are sent to clients via the open socket connections whenever the status of an input or output changes.

Basically, any third-party controller that can implement the FNIP-12xDIO's simple communication protocol can control the module. The following controllers are the most widely used:

- AMX
- Control4
- Crestron
- RTI
- Savant
- Fibaro
- Extron
- Neets (biamp)
- Home Assistant
- QSYS

Software modules/plug-ins for controllers are either available or P5 will provide full assistance in creating them.

Besides these special-purpose controllers, there have been many applications for embedded industrial PC boards, PCs and smartphones running Linux, Windows, Mac OS.

TECHNICAL SPECIFICATIONS

Power Requirements		
	12 – 24 VDC (10.8V - 36V DC), max 280 mA @ 12V, 150 mA @ 24V	
Outputs		
Type	12 x SPST NO, dry contacts	
Load	max. 5A@250VAC or 24VDC	
Inputs		
Type	12 digital inputs	
Communication		
Control	TCP (simple ASCII TCP command) Built-in web server Local inputs (resistance detection)	
Channel modes	Toggle, monostable, input follow, independent	
Interoperability	Drivers available for most systems	
Connectors		
Input Terminals	1.5mm ² screw terminals	
Output Terminals	2.5mm ² screw terminals	
LAN (10Mb/s)	RJ45 Ethernet Connector	
Environmental		
Operating Temperature	0 °C – 40 °C (32 °F – 104 °F)	
Storage Temperature	-20 °C – 60 °C (-4 °F – 140 °F)	
Humidity	Up to 93% (Non condensing)	
Physical		
Dimensions (H x W x D)	157 mm x 86 mm x 57 mm (9 DIN unit width)	
Weight	0.38Kg	
Installation	Standard DIN Rail Mount	
Approvals	Package Content	Warranty
CE	FNIP-12xDIO	2 years